

Rear Spoiler Installation Instructions



**Lifetime
Warranty**

Kit Includes:

Spoiler
Gaskets
Plastic Locator T-Strips
Mounting Screws
Rust Prohibitor
Lit Spoilers also include:
(2) 3M Scotchlock™ connectors
Split Loom

Tools Required:

Drill
Brill Bits (1/8", 5/16", and 3/4")
Panel Puller
3/8" Ratchet or Nut Driver
Measuring Tape
Pliers
Masking Tape



STEP 1.

After opening and inspecting your Wings Direct rear spoiler you can begin the installation. Notice that the LED light comes pre-installed from the factory. Make certain to test fit and verify color match before proceeding to step 2. If there are any problems please call 1-800-733-3316, immediately.

STEP 2.

Start out by turning over the spoiler and setting it on a soft surface, to prevent any scratches. Place the plastic locator T-strips into the mounting holes on spoiler and LED brake light hole. TIP: A small piece of masking tape is helpful in holding the T-strips in position.



STEP 3.

Place spoiler on closed decklid and align to proper position. A measuring tape will ensure a "perfect" alignment.

STEP 4.

Using masking tape, secure locator T-strips to the decklid of the vehicle. Simply remove the spoiler by lifting straight up leaving the T-strips secured to the decklid.



STEP 5.

Using a 1/8" drill bit, drill thru the T-strip holes and into the decklid. It is not necessary to drill through a double panel on this particular application because we can utilize the factory openings on the underside.

STEP 6.

Remove T-strips and using a 5/16" drill bit, drill thru the 1/8" hole in step 5. If a "double panel" does exist, use a 3/4" drill bit to drill thru the "inner panel". This allows the ratchet or nutdriver to secure the screw tightly against the upper panel.



STEP 7.

After deburring all holes, apply small amounts of rust proofing to help prevent rusting of the freshly drilled metal.

STEP 8.

Pull back pedestal gaskets exposing mounting tape and place spoiler on decklid and using supplied screws secure to the vehicle using a ratchet or nutdriver. Be sure to feed the LED light wire through the pre-determined hole. Apply small amounts of silicone based caulk over mounting screws as this will help prevent leaking, rusting, or loosening of screws. TIP: Gasket material is extremely sticky once exposed, so we found that spraying it with water or glass cleaner will allow you to reposition spoiler as needed.



STEP 9.

When installing a LED brake light it is recommended to splice into the 3rd brake light in the vehicle and attach spoiler wires using supplied 3M Scotchlock™ connectors. Step on the brake light to ensure proper wiring, simply switch the two connections if spoiler does not light. All lights are tested prior to installation, if the light does not work please double check your connections and condition of wire. If it still fails to light, reverse the wires and try again.

STEP 10.

Finish your install by vacuuming any debris or metal shavings and then reinstall any panels, mats or other items that may have been removed earlier in installation.



1-800-733-3316